



Analysis Report

Water/Gas Samples

HAG-GT1 Well

PanTerra Geoconsultants BV
Weversbaan 1-3
2352 BZ Leiderdorp
the Netherlands

T +31 (0)71 5 81 35 05
F +31 (0)71 3 01 08 02
info@panterra.nl
www.panterra.nl

Company registration: 28047512
VAT registration: NL0091.32.582.B01

ABN Amro Bank: 49.28.54.319
Stationsweg 31-33, Leiden
IBAN: NL13 ABNA 0492 8543 19
SWIFT: ABNANL2A



CONTENTS

| | |
|--|-----------|
| 1. PROCEDURES DESCRIPTION | 3 |
| 1.1. SAMPLING SEQUENCE..... | 3 |
| 1.2. SAMPLES PRELIMINARY CHECKS AND ANALYSIS..... | 3 |
| 1.2.1. <i>Visual Inspection upon Receiving the Samples</i> | 3 |
| 1.2.2. <i>Opening Pressure Measurement</i> | 3 |
| 1.2.3. <i>Gas Bottle Water Check</i> | 3 |
| 1.2.4. <i>Gas H₂S Presence Check</i> | 3 |
| 1.2.5. <i>Samples Restoration</i> | 4 |
| 1.2.6. <i>Bubble Point Measurements</i> | 4 |
| 1.2.7. <i>Compositional Analysis</i> | 5 |
| 1.2.7.1. <i>Flash Separation</i> | 5 |
| 1.2.7.2. <i>Sample Composition</i> | 5 |
| 2. PROVIDED INFORMATION | 8 |
| 2.1.1. <i>Summary of Well Data</i> | 8 |
| 2.1.2. <i>Summary of Sampling Data</i> | 8 |
| 3. ANALYSIS RESULTS..... | 9 |
| 3.1. PRELIMINARY CHECK RESULTS | 9 |
| 3.2. COMPOSITIONAL ANALYSIS | 10 |
| 3.3. GRAPHS..... | 14 |
| 4. CONCLUSIONS | 20 |

INDEX OF FIGURES

| | |
|--|----|
| FIGURE 1-GAS SAMPLES QUALITY CHECK | 4 |
| FIGURE 2-BUBBLE POINT MEASUREMENT | 4 |
| FIGURE 3-FLASH SEPARATION | 5 |
| FIGURE 4-GENERAL CHROMATOGRAPHIC PROCEDURE LAYOUT..... | 6 |
| FIGURE 5-GAS CHROMATOGRAPHY LAYOUT | 7 |
| FIGURE 6-BUBBLE POINT MEASUREMENT – SAMPLE NO. F8009/156 | 14 |
| FIGURE 7-BUBBLE POINT MEASUREMENT – SAMPLE NO. 32138 | 15 |
| FIGURE 8-GAS CHROMATOGRAM SAMPLE NO. DW-7214 | 16 |
| FIGURE 9-FLASHED GAS CHROMATOGRAM SAMPLE NO. F8009/156 | 17 |
| FIGURE 10-FLASHED GAS CHROMATOGRAM SAMPLE NO. 32138 | 18 |
| FIGURE 11-GAS CHROMATOGRAM, PLASTIC BALOON SAMPLE | 19 |

INDEX OF TABLES

| | |
|--|----|
| TABLE 1-SUMMARY OF SAMPLING DATA | 8 |
| TABLE 2-PRELIMINARY CHECK RESULTS..... | 9 |
| TABLE 3-GAS COMPOSITION SAMPLE NO. DW-7214 | 10 |
| TABLE 4-FLASHED GAS COMPOSITION SAMPLE NO. F80009/156..... | 11 |
| TABLE 5-FLASHED GAS COMPOSITION SAMPLE NO. 32138..... | 12 |
| TABLE 6-GAS COMPOSITION SAMPLE PLASTIC BALOON | 13 |

1. Procedures Description

1.1. Sampling Sequence

The sampling kit with a purging tee was connected to a branch manifold from the drillpipe. The water well was choked to 250 psi for 15 minutes. A purge was conducted to determine the nature of the sample, the sample collected at the purge tee was just gas with very little liquid.

After flowing the well for 1 hour at a rate of 150 m³/hour, the sample was collected using the displacement procedure from the branch manifold at 14:45. During the sampling, the well was flowing at a pressure of about 100 psi and a rate of 140m³/hour.

The second pressurized liquid sample was collected after an hour of well flowing, again at 140 m³/hour and 100 psi.

The pressurized gas sample was collected at 16:15 with the well flowing, with a backpressure of 250psi.

An additional atmospheric gas sample was collected in a balloon from the annulus.

1.2. Samples Preliminary Checks and Analysis

1.2.1. Visual Inspection upon Receiving the Samples

Upon receipt, the samples were visually inspected for any obvious faults, i.e. leaks, bent valves or any other mechanical problems. The sample cylinders were all found to be in good condition.

1.2.2. Opening Pressure Measurement

The pressurized sample cylinders at room temperature were connected at the water end to a high pressure pump, the opening pressure was read at the pump display.

For the gas cylinder, a pressure gauge was attached to the top valve at room temperature. The opening pressure was read directly at the gauge.

1.2.3. Gas Bottle Water Check

With the gas sample in a vertical position, a few cc's were purged from the bottom valve in order to check the water content. All the water found was drained.

1.2.4. Gas H₂S Presence Check

With the gas sample in a vertical position, a few cc's were purged on a paper strip imbibed with Lead Acetate. H₂S reacts specifically with lead acetate to form a lead sulfide brown stain. There was a very slight change in color indicating that there was some infinitesimal H₂S amount. During the purge, some H₂S smell could be vaguely perceived.




Figure 1-Gas Samples Quality Check

1.2.5. Samples Restoration

The liquid samples were pressurized to the working pressure and stabilized by shaking. While connected to a positive displacement pump, the samples were heated up to a temperature of 95°C and homogenized for 24 hours prior to any removal of samples.

1.2.6. Bubble Point Measurements

The liquid samples were subjected to pressures ranging from pressures higher than the reservoir pressure to much lower pressures at reservoir temperature.

The change in the slope of the PV curve indicates the bubble point pressure.




Figure 2-Bubble Point Measurement

1.2.7. Compositional Analysis

1.2.7.1. Flash Separation




Figure 3-Flash Separation

A volume of a single-phase fluid was pumped from the sample cylinder into a trap connected to a gas meter at atmospheric conditions of pressure and temperature. The flashed water and gas volumes, separation temperatures and atmospheric pressures were accurately recorded.

The composition of gas was subsequently measured using the procedure described below. The flash GOR (gas oil ratio) was calculated as well as the ratio between the flashed liquid and the collected gas.

1.2.7.2. Sample Composition

The resulted gas fraction was analysed using the gas chromatography procedure.




Figure 4-General Chromatographic Procedure Layout

Compositions up to C_{11+} were measured. Components: porous polymer and mole sieve columns, TCD detector (for C_1 - C_3 , permanent gases), capillary column and FID detector (for C_4 to C_{11+}).




Figure 5-Gas Chromatography Layout

2. Provided Information

2.1.1. Summary of Well Data

Well: HAG-GT1

Reservoir Fluid: Water/Gas

Reservoir Pressure: 3300 psi

Reservoir temperature: 75°C

Vertical Depth: 2301 m

2.1.2. Summary of Sampling Data

Table 1-Summary of Sampling Data

| Sample type | Well | Sampling Point | Original bottle no. | Date/Time Sampling | Surface Line Pressure (psi) |
|--------------------|---------|-------------------------------|---------------------|--------------------|-----------------------------|
| Pressurized Liquid | HAG-GT1 | Surface – Drill Pipe Manifold | F80009/156 | 22-9-10/14:45 | 100 |
| Pressurized Liquid | HAG-GT1 | Surface – Drill Pipe Manifold | 32138 | 22-9-10/15:45 | 100 |
| Pressurized Gas | HAG-GT1 | Surface – Drill Pipe Manifold | DW-7214 | 22-9-10/16:00 | 100 |
| Atmospheric Gas | HAG-GT1 | Surface - Annulus | Plastic Recipient | 22-9-10/16:30 | 250 (back pressure) |

3. Analysis Results

3.1. Preliminary Check Results

Table 2-Preliminary Check Results

| Sample Type | Cylinder no. | Opening Pressure (psig) | Opening Temperature (°C) | Sample Volume (cc) | Bubble Point (psig) at 75°C |
|--------------------|--------------|-------------------------|--------------------------|--------------------|-----------------------------|
| Pressurized Liquid | F80009/156 | 80 | 22 | 700 | 1320 |
| Pressurized Liquid | 32138 | 84 | 22 | 700 | 1100 |
| Pressurized Gas | DW-7214 | 380 | 50 | 20000 | N/A |

* Sample volume at opening pressure

3.2. Compositional Analysis

Table 3-Gas Composition Sample no. DW-7214

| | Component | Mole% | Weight% |
|---|-------------------|---------|---------|
| H ₂ | Hydrogen | 0.000 | 0.000 |
| H ₂ S | Hydrogen Sulphide | 0.000 | 0.000 |
| CO ₂ | Carbon Dioxide | 1.697 | 4.267 |
| N ₂ | Nitrogen | 2.424 | 3.879 |
| C1 | Methane | 93.074 | 85.286 |
| C2 | Ethane | 2.066 | 3.548 |
| C3 | Propane | 0.428 | 1.077 |
| C4 | i-Butane | 0.039 | 0.130 |
| C4 | n-Butane | 0.051 | 0.168 |
| C5 | i-Pentane | 0.008 | 0.033 |
| C5 | n-Pentane | 0.004 | 0.018 |
| C6 | Hexanes | 0.009 | 0.044 |
| C7 | Heptanes | 0.003 | 0.015 |
| C8 | Octanes | 0.001 | 0.005 |
| C9 | Nonanes | 0.000 | 0.001 |
| C10 | Decanes | 0.156 | 1.192 |
| C11+ | Undecanes Plus | 0.040 | 0.337 |
| | Total | 100.000 | 100.000 |
| Calculated Gas Properties | | | |
| Gas Density (kg m ⁻³ @ 15°C) | | 0.740 | |
| Gas Mole Weight (g mol ⁻¹) | | 17.508 | |
| Real Relative (to air) Density of Gas | | 0.604 | |
| Mole weight of Heptanes Plus (g mol ⁻¹) | | 135.569 | |
| Density of Heptanes plus (g cm ⁻³ at 60°F) | | 0.781 | |
| Mole Weight of Undecanes plus (g mol ⁻¹) | | 147.000 | |
| Density of Undecanes plus (g cm ⁻³ at 60°F) | | 0.789 | |
| Calorific Value (MJ m ⁻³) | | 37.545 | |

Table 4-Flashed Gas Composition Sample no. F80009/156

| | Component | Mole% | Weight% |
|---|-------------------|---------|---------|
| H ₂ | Hydrogen | 0.000 | 0.000 |
| H ₂ S | Hydrogen Sulphide | 0.000 | 0.000 |
| CO ₂ | Carbon Dioxide | 3.371 | 5.147 |
| N ₂ | Nitrogen | 1.521 | 1.478 |
| C1 | Methane | 77.860 | 43.337 |
| C2 | Ethane | 1.802 | 1.880 |
| C3 | Propane | 2.082 | 3.186 |
| C4 | i-Butane | 0.499 | 1.006 |
| C4 | n-Butane | 2.827 | 5.700 |
| C5 | i-Pentane | 0.907 | 2.271 |
| C5 | n-Pentane | 2.515 | 6.296 |
| C6 | Hexanes | 1.007 | 2.934 |
| C7 | Heptanes | 0.344 | 1.084 |
| C8 | Octanes | 0.626 | 2.034 |
| C9 | Nonanes | 0.009 | 0.037 |
| C10 | Decanes | 0.001 | 0.005 |
| C11+ | Undecanes Plus | 4.628 | 23.604 |
| | Total | 100.000 | 100.000 |
| Calculated Gas Properties | | | |
| Gas Density (kg m ⁻³ @ 15°C) | | 0.935 | |
| Gas Mole Weight (g mol ⁻¹) | | 28.823 | |
| Real Relative (to air) Density of Gas | | 0.763 | |
| Mole weight of Heptanes Plus (g mol ⁻¹) | | 137.548 | |
| Density of Heptanes plus (g cm ⁻³ at 60°F) | | 0.792 | |
| Mole Weight of Undecanes plus (g mol ⁻¹) | | 147.000 | |
| Density of Undecanes plus (g cm ⁻³ at 60°F) | | 0.789 | |
| Calorific Value (MJ m ⁻³) | | 45.407 | |

Flash Gas Water Ratio: 1.235 Nm³/m³

Table 5-Flashed Gas Composition Sample no. 32138

| | Component | Mole% | Weight% |
|---|-------------------|---------|---------|
| H ₂ | Hydrogen | 0.000 | 0.000 |
| H ₂ S | Hydrogen Sulphide | 0.000 | 0.000 |
| CO ₂ | Carbon Dioxide | 5.292 | 12.080 |
| N ₂ | Nitrogen | 2.037 | 2.959 |
| C1 | Methane | 88.521 | 73.661 |
| C2 | Ethane | 1.827 | 2.849 |
| C3 | Propane | 0.485 | 1.109 |
| C4 | i-Butane | 0.064 | 0.194 |
| C4 | n-Butane | 0.363 | 1.095 |
| C5 | i-Pentane | 0.137 | 0.513 |
| C5 | n-Pentane | 0.407 | 1.522 |
| C6 | Hexanes | 0.412 | 1.795 |
| C7 | Heptanes | 0.180 | 0.852 |
| C8 | Octanes | 0.265 | 1.307 |
| C9 | Nonanes | 0.009 | 0.056 |
| C10 | Decanes | 0.001 | 0.008 |
| C11+ | Undecanes Plus | 0.000 | 0.001 |
| | Total | 100.000 | 100.000 |
| Calculated Gas Properties | | | |
| Gas Density (kg m ⁻³ @ 15°C) | | 0.818 | |
| Gas Mole Weight (g mol ⁻¹) | | 19.279 | |
| Real Relative (to air) Density of Gas | | 0.667 | |
| Mole weight of Heptanes Plus (g mol ⁻¹) | | 94.041 | |
| Density of Heptanes plus (g cm ⁻³ at 60°F) | | 0.797 | |
| Mole Weight of Undecanes plus (g mol ⁻¹) | | 147.000 | |
| Density of Undecanes plus (g cm ⁻³ at 60°F) | | 0.789 | |
| Calorific Value (MJ m ⁻³) | | 38.049 | |

Flash Gas Water Ratio: 0.701 Nm³/m³

Table 6-Gas Composition Sample Plastic Balloon

| | Component | Mole% | Weight% |
|---|-------------------|---------|---------|
| H ₂ | Hydrogen | 0.000 | 0.000 |
| H ₂ S | Hydrogen Sulphide | 0.000 | 0.000 |
| CO ₂ | Carbon Dioxide | 0.038 | 0.099 |
| N ₂ | Nitrogen | 1.653 | 2.760 |
| C1 | Methane | 95.455 | 91.250 |
| C2 | Ethane | 2.183 | 3.912 |
| C3 | Propane | 0.497 | 1.307 |
| C4 | i-Butane | 0.051 | 0.176 |
| C4 | n-Butane | 0.061 | 0.210 |
| C5 | i-Pentane | 0.011 | 0.046 |
| C5 | n-Pentane | 0.021 | 0.089 |
| C6 | Hexanes | 0.028 | 0.138 |
| C7 | Heptanes | 0.002 | 0.010 |
| C8 | Octanes | 0.001 | 0.003 |
| C9 | Nonanes | 0.000 | 0.000 |
| C10 | Decanes | 0.000 | 0.000 |
| C11+ | Undecanes Plus | 0.000 | 0.000 |
| | Total | 100.000 | 100.000 |
| Calculated Gas Properties | | | |
| Gas Density (kg m ⁻³ @ 15°C) | | 0.711 | |
| Gas Mole Weight (g mol ⁻¹) | | 16.782 | |
| Real Relative (to air) Density of Gas | | 0.580 | |
| Mole weight of Heptanes Plus (g mol ⁻¹) | | 88.446 | |
| Density of Heptanes plus (g cm ⁻³ at 60°F) | | 0.783 | |
| Mole Weight of Undecanes plus (g mol ⁻¹) | | 147.000 | |
| Density of Undecanes plus (g cm ⁻³ at 60°F) | | 0.789 | |
| Calorific Value (MJ m ⁻³) | | 38.219 | |

3.3. Graphs




Figure 6-Bubble Point Measurement – Sample no. F8009/156

Bubble Point Pressure at 75°C
Sample no.32138




Figure 7-Bubble Point Measurement – Sample no. 32138




Figure 8-Gas Chromatogram Sample no. DW-7214




Figure 9-Flashed Gas Chromatogram Sample no. F8009/156




Figure 10-Flashed Gas Chromatogram Sample no. 32138




Figure 11-Gas Chromatogram, Plastic Balloon sample

4. Conclusions

In order to obtain a representative sample, the recommended method of sampling is bottomhole sampling, which gives the possibility of collecting a single phase sample from the formation level thus preventing the subsequent change in composition (flash). Surface sampling is recommended where there is a separator at surface and the flow rates of both separated fluids (liquid and gas) can be accurately measured.

In the case of the well Hag-GT1 neither of the two scenarios above were possible, therefore the samples were collected without the certainty that the fluid was flowing in single phase. Depending on the degree of choking, various types of fluids (gas, wet gas, water with bursts of gas etc) were encountered during purging process.

Bubble points were lower than the reservoir pressure at reservoir temperature, but different from each other. The gas water ratios were different from each other, i.e. different fluids were flowing through the manifold at the sampling times. Moreover, the gases flashed from the two pressurized samples, the 20l gas sample and the gas sample collected in a plastic balloon were all compositionally different (the 20 l gas sample and the gas balloon appear closer to each other and probably to the real gas composition).

Consequently, there is no way of guaranteeing the representativity of the samples. If the well was flowing with more gas than it actually contains dissolved in the water in the reservoir, then the sample bubble point would be artificially high and the opposite is true for a flow of degassed water.

Although the H₂S presence was detected by Lead Acetate Strip Paper and by smell, there was no H₂S peak during the compositional analysis due to the following:

- extremely low concentration, close to the lower limit of the GC equipment (5 ppm)
- possible absorption of part of the already infinitesimal amount into the metal parts of the sampling equipment (sampling hose, lines, cylinder).
- the sampling flowing in two phases and thus releasing the gas fraction leading to the above absorption in all metal parts.

Sampling during unstable (two phase) flow is not recommended for very accurate H₂S determination. A wellsite portable measurement equipment could provide much more accurate results (i.e. Draeger tubes with Accuro Pumps) with an accuracy of 0.2-5 ppm H₂S.